

# Promise Solutions

## Reglazing Examples



### Reglazing Tips

You do not have to make it look perfect. Just scrape off as much old silicone as possible. Then put the glass in and seal it. No tape is needed. This should be quick and easy.

Here is a video on **how to cut glass**. Instead of applying pressure, use the end of the cutting tool and tap (lightly) along the scored line.

<https://www.youtube.com/watch?v=yICSFk7nCJ0>

Many first-timers take a piece of the **old broken window and practice a few times** on cutting/breaking so you can get the hang of it before you install the new glass. Practice makes perfect.

[https://www.youtube.com/watch?v=yASNMzhi\\_Do](https://www.youtube.com/watch?v=yASNMzhi_Do)

<https://www.youtube.com/watch?v=goRcunMEF2I>

**Link to the glass tool:**

<https://www.homedepot.com/s/glass%20cutting%20tool?NCNI-5>

# Reglazing Examples



## **BEFORE PHOTOS**

- Showing the entire window.
- Showing both measurements: length & width.
- Showing section of the house, if multiple windows.
- \*\*Closeup on tape measure, and measurement markers. (See after photos for example.)\*\*



# Reglazing Examples



# Reglazing Examples



## DURING PHOTOS

- Showing old glass removed.
- Showing action shots of the installation.



# Reglazing Examples

## AFTER PHOTOS

- Perspective shots.
- Measurements of length and width.
- After photos without tape measure.
- Count to show different windows when reglazing multiple windows.



# Reglazing Examples

